




1 Removing the Printer Rear Cover:


1




2



3



4



2 Installing the Tractor Assembly:

